

Setting Up Your 3D Scanner

1. Set Up Your 3D Scanner Kit

Please keep in mind that the results this 3D scanner kit delivers are dependent on how well it is put together. With that being said:

Place your Laser Holder with the Laser into in the RIGHT Slot of the ASCAND Body with the Laser pointing at the Turn Table

Connect the Laser to the Battery and switch it on

2. Calibrate your 3D Scanner

Align the blue center line on this Laser Calibration Plate pointing perpendicular towards the center of the ASCAND Body

Turn the Focus Ring at the Front of the Laser until you see a CRISP Laser Line on this round Laser Calibration Plate and align it with the red line by turning the Laser Focus Ring

Remove this Calibration Plate from your Turn Table to uncover the black velvet Turn Table surface and store it safely for future use

Center Line